Ohaus Corporation
19A Chapin Road
P.O. Box 2033
Pine Brook, NJ 07058-2033 USA
www.ohaus.com

Ohaus CS Postal Scale Accessory – Letter Holder

Installation Instructions

1. Carefully remove the wire frame from the packaging.

2. The stainless steel pan cover is already fitted to the scale pan, but can be removed while fitting the wire frame if required.

3. Press one side of the wire frame under the locating tabs already stamped in the stainless steel pan cover. Compress the wire frame to locate the other side of the frame under the corresponding tabs on the other side of the pan cover.

4. The larger wire frame should be nearest the rear of the scale.

5. To make the installation more permanent the locating tabs may be pushed down with a blunt instrument to tighten around the wire frame. The wire frame and/or the stainless steel pan cover may be removed for cleaning or transportation.

80250978

P/N 80250978 © Ohaus Corporation 2003, all rights reserved.
Printed in China